MF229dw如何從本機掃描 MF229dw How to scanning from the Machine

1. 放置文件(Place the document(s))



2. 按 📵 並點選 <掃描> (Press 📵 and tap <Scan>)



3. 點選 <電腦> (Tap <Computer>)



4. 選擇接收者電腦,如果只有一台電腦透過 USB 連接本機,不會顯示此畫面

(Select the destination computer. This screen is not displayed if only a computer is connected to the machine via USB)



5. 選擇掃描類型 (Select the scan type)



- 6. 按圖開始掃瞄 (Press to starts scanning)
- 7. 如在步驟 1 將文件放在送稿機中,掃描完成後,電腦會顯示儲存資料夾 Windows預設掃描資料夾: [圖片] 或 [我的圖片]

Mac OS預設掃描資料夾:[圖片]

(When placing documents in the feeder in step 1, the save destination folder is displayed on the computer after scanning is complete.

Windows, the default folder for scanned data: [Pictures] or [My Pictures]

Mac OS, the default folder for scanned data: [Pictures])

■ 如在步驟 1 將文件放在原稿台玻璃上,請按照以下步驟操作 (When placing documents on the platen glass in step 1, follow the procedure below)

掃描下一份:按「啟動」	
確認接收者	
取消	完成掃描

如果還要掃描其他文件頁面,將下一份文件放置在原稿台玻璃上,然後按

(If there are additional pages of documents to be scanned, place the next document on the platen glass, and press)

重複此步驟,直到所有頁面都完成掃描

(Repeat this step until you finish scanning all of the pages)

點選 <完成掃描>後電腦會顯示儲存資料夾

Windows預設掃描資料夾:[圖片]或[我的圖片]

Mac OS預設掃描資料夾: [圖片]

(Tap <Finish Scan> and the save destination folder is displayed on the computer. Windows, the default folder for scanned data: [Pictures] or [My Pictures]

Mac OS, the default folder for scanned data: [Pictures])