


EOS-1D X Mark II無線連接至電腦（使用EOS Utility應用程式）  
EOS-1D X Mark II wireless connect with computer (use EOS Utility application)

1. 安裝傳輸器WFT-E6D或WFT-E8D，然後開啟相機  
Attach the transmitter WFT-E6D or WFT-E8D, and then turn on the camera



2. 在相機上，按下<MENU>按鈕。在 [43] 設定頁下，選擇 [通訊設定]  
On the camera, press the <MENU> button. Under the [43] tab, select [communication settings]



3. 選擇 [通訊功能] 中的 [啟用]  
Select [Enable] in [Communication func]



4. 選擇 [網路設定]

Select [Network settings]



5. 選擇 [連接設定]

Select [Connection settings]



6. 選擇 [SET\*]

Select [SET\*]




7. 選擇 [連接精靈]

Select [Connection wizard]



8. 選擇通訊方法為 [EOS Utility]，然後選擇 [確定]

Select [EOS Utility], and then select [OK]



9. 選擇 [無線]，然後選擇 [確定]

Select [Wireless], and then select [OK]




10. 選擇 [簡易連接]，然後選擇 [確定]  
Select [Easy connection], and then select [OK]




11. 啟動電腦的Wi-Fi功能，然後選擇相機螢幕上顯示的SSID；而密碼請輸入相機螢幕上顯示的加密金鑰  
Activate the Wi-Fi function of the smartphone, then select the SSID (network name) displayed on the camera's LCD monitor; for the password, enter the encryption key on the camera's LCD monitor.

相機螢幕畫面  
Camera's Screen



電腦螢幕 (範例)  
Computer's screen (sample)



12. 選擇 [確定]

Select [OK]



13. 當相機的液晶螢幕中會顯示以下訊息，請在電腦上啟動EOS Utility

When the screen below will appear on the camera's LCD monitor, please start EOS Utility on the computer



14. 請在電腦上啟動EOS Utility


Please start EOS Utility on the computer




15. 在EOS Utility中，按一下 [透過Wi-Fi / LAN配對 (Pairing over Wi-Fi / LAN) ]  
In EOS Utility, click [Pairing over Wi-Fi / LAN]



16. 如果出現以下畫面，請按「是」  
If the screen as below appears, please click "Yes"



17. 點選相機，然後按一下 [連接 (Connect) ]  
Select camera, and then click [Connect]



18. 選擇 [確定]  
Select [OK]




19. 選擇 [確定]  
Select [OK]



20. 與EOS Utility連接的設定到此完成

The setting for connecting to EOS Utility is now completed



-完-  
-End-