Canon Camera Connect 支援的功能(EOS 數碼單鏡反光相機)
Canon Camera Connect - Supported function(EOS Digital SLR Camera)

功能 Function / 相機型號 Model	影像傳輸 Image Transfer 相片 Still Image	短片 Video	遙控拍攝 Remote Shooting	藍芽遙控 Bluetooth Remote Control	短片遙控拍攝 Movie Remote Shooting	相機存取點模式 Camera Access Point Mode	網絡架構模式 Infrastructure Mode	NFC
EOS-1D X MK II + WFT-E8D	JPEG / RAW	MP4	✔	-	✔	✔	✔	-
EOS 5D MK IV	JPEG / RAW	MP4	✔	-	✔	✔	✔	✔
EOS 5DS + W-E1	JPEG / RAW	MP4	✔	-	-	✔	✔	-
EOS 5DS R + W-E1	JPEG / RAW	MP4	✔	-	-	✔	✔	-
EOS 6D	JPEG / RAW	-	✔	-	-	✔	✔	-
EOS 6D Mark II	JPEG / RAW	MP4	✔	✔	✔	✔	✔	✔
EOS 7D MK II + W-E1	JPEG / RAW	MP4	✔	-	-	✔	✔	-
EOS 80D	JPEG / RAW	MP4	✔	-	✔	✔	✔	✔
EOS 70D	JPEG / RAW	-	✔	-	-	✔	✔	-
EOS 77D	JPEG / RAW	MP4	✔	✔	-	✔	✔	✔
EOS 200D	JPEG / RAW	MP4	✔	✔	✔	✔	✔	✔
EOS 760D	JPEG / RAW	MP4	✔	-	-	✔	✔	✔
EOS 800D	JPEG / RAW	MP4	✔	✔	-	✔	✔	✔
EOS 750D	JPEG / RAW	MP4	✔	-	-	✔	✔	✔
EOS 1300D	JPEG / RAW	-	✔	-	-	✔	✔	✔
EOS M5	JPEG / RAW	MP4	✔	✔	-	✔	✔	✔
EOS M6	JPEG / RAW	MP4	✔	✔	-	✔	✔	✔
EOS M3	JPEG / RAW	MP4	✔	-	-	✔	✔	✔
EOS M2	JPEG / RAW	-	✔	-	-	✔	✔	-
EOS M10	JPEG / RAW	MP4	✔	-	✔	✔	✔	✔

Canon Camera Connect - 即時遙控拍攝的支援功能(數碼輕便相機)
Canon Camera Connect - Supported function on remote live view shooting(Digital Compact Camera)

相機型號 Model	相片 Still Image	短片 Video	短片遙控拍攝 Movie Remote Shooting	藍芽遙控 Bluetooth Remote Control	快門 Shutter	變焦 Zoom	閃燈設定 Flash Setting	定時自拍 Self-Timer	連續拍攝 Continuous Shooting	長寬比 Aspect Ratio	對焦框顯示 Focus Frame Display	自動對焦模式 AF Method Setting	自動對焦按鈕 AF Button	AV / TV / ISO / 曝光補償 Exposure Compensation	移動對焦框 Focus Frame Movement	B快門秒數顯示 BULB mode time display
PS G3X	JPEG / RAW	MP4	-	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔
PS G5X	JPEG / RAW	MP4	-	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔
PS G7X MKII	JPEG / RAW	MP4	-	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔
PS G9 X	JPEG / RAW	MP4	-	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔
PS G9X II	JPEG / RAW	MP4	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔
PS SX730 HS	JPEG	MP4	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	-	-
PS SX720 HS	JPEG	MP4	-	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	-	-
PS SX710 HS	JPEG	MP4	-	-	✔	✔	✔	✔	✔	✔	✔	✔	✔	✔	-	-
PS G1X MK II	JPEG / RAW	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS G7X	JPEG / RAW	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS SX60 HS	JPEG / RAW	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS SX530 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS SX420 IS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS SX700 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS SX620 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS SX610 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
PS SX600 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
IXUS 285 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
IXUS 275 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
IXUS 265 HS	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
IXUS 180	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
IXUS 190	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
N100	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-
N2	JPEG	MP4	-	-	✔	✔	✔	✔	-	-	-	-	-	-	-	-