
LBP214dw 在 Windows 透過 WIFI 連線連接印表機之驅動程式步驟 Driver installation procedure for LBP214dw in Windows (Via WIFI)

先將打印機連接到路由器,詳細可參考以下步驟:

The Connection by selecting a wireless router:

- 1. 在首頁畫面中選擇 <功能表>。 Select "Menu" in the Home Screen
- 2. 選擇「參數選擇」>「網路」 Select "Preference" > "Network"
- 若顯示 PIN 碼輸入畫面,請便用數字鍵輸入 PIN 碼,然後點選「套用」
- If the screen for entering a PIN appears, enter the correct PIN and select "Apply"
- 3. 選「無線區域網路設定」 Select "Wireless LAN Settings"
- 4. 閱讀顯示訊息後按"OK" Read the message that is displayed, and select "OK".
- 5. 選「SSID 設定」 Select "SSID setting"
- 6. 選「選擇存取點」 Select "Select Access Point"
- 7. 選擇無線區域網路路由器

Select the router SSID



- 8. 輸入您記下的網路鍵值 使用數字鍵輸入網路金鑰(路由器密碼),然後點選「套用」 Enter the network key using the numeric keys, and select "Apply"
- 9. 點選「是」 Select "yes"
- 10. 等待直至顯示<已連接>,選<關閉> Wait until message <Connected.> is displayed. Select <Close>

下載及安裝步驟

Driver download and Installation procedure

11. 到佳能網站 https://hk.canon/en/support/imageCLASS%20LBP214dw/model,下載印表機的驅動程式

Go to: https://hk.canon/en/support/imageCLASS%20LBP214dw/model, download the printer driver

12. 選擇並下載以下檔案


Choose and download below file:

- 打印機驅動程式 / Printer Driver

[Windows xxbit] Generic Plus UFR II Printer Driver Vx.xx


13. 下載的文件以自解壓縮檔檔案(.exe 格式)保存在指定的文件夾中,打開文件解壓縮。將在同一文件夾中創建新文件夾。新文件夾的名稱與解壓縮文件的名稱相同,進入新文件夾開啟「Setup.exe」開始安裝

Open the downloaded file, a same name new folder will be created. Go into new folder open "Setup.exe" start installation"



14. 選擇語言(Language),然後按「Next」

Select Language, press "Next"



15. 選擇「Yes」

Choose "Yes"

License Agreement

Please read the following license agreement completely and carefully. Click [Yes] to agree to the license agreement.




CANON SOFTWARE LICENSE AGREEMENT IMPORTANT This is a legal agreement ("Agreement") between you and Canon Inc. ("Canon") and governing your use of Canon's software programs including the related manuals or any printed material thereof (the "SOFTWARE") for certain Canon's copying machines, printers and multifunctional peripherals (the "Products"). READ CAREFULLY AND UNDERSTAND ALL OF THE RIGHTS AND RESTRICTIONS DESCRIBED IN THIS AGREEMENT BEFORE > Do you agree to the terms in license agreement?

16. 選擇「Standard」,按「Next」

Choose "Standard", press "Next"


The Generic Plus UFR II printer driver will be installed on your computer. Select a setup method, and then click [Next].






17. 按「Next」

Press "Next"




18. 等待搜尋印表機

Wait for searching printer




19. 勾選印表機,按「Next」

Select the printer, press "Next"




20. 確定印表機資料,按「Start」

Confirm printer information, press "Start"



21. 等待安裝程序完成

Waiting for the installation progress



按「Exit」完成安裝 22.

Click "Exit" to finish installation



-完--End-