LBP913w 在 Windows 透過 WIFI 連線連接印表機之驅動程式步驟 Driver installation procedure for LBP913w in Windows (Via WIFI)

先將打印機連接到路由器,詳細可參考以下步驟:

The Connection by selecting a wireless router:

1. 在首頁畫面中選擇 <功能表>

Select "Menu" in the Home Screen

2. 選擇「網路設定」

Select "Network Settings"

- 若顯示 PIN 碼輸入畫面,請便用數字鍵輸入 PIN 碼,然後點選「套用」
- If a screen for entering a PIN is displayed, enter the PIN with the numeric keys and tap "Apply"
- 3. 選「無線區域網路設定」

Select "Wireless LAN"

4. 閱讀顯示訊息後按"OK"

Read the message that is displayed, and select "OK"

5. 選「SSID 設定」


Select "SSID setting"

6. 選「選擇存取點」

Select "Select Access Point"

7. 選擇無線區域網路路由器

Select the router SSID



8. 輸入您記下的網路鍵值

使用數字鍵輸入網路金鑰(路由器密碼),然後點選「套用」 Enter the network key using the numeric keys, and select "Apply"

9. 點選「是」

Select "yes"

10. 等待直至顯示<已連接>,選<關閉>

Wait until message <Connected.> is displayed. Select <Close>

下載及安裝步驟

Driver download and Installation procedure

- 11. 到佳能網站https://hk.canon/en/support/imageCLASS%20LBP913w/model, 下載印表機的驅動程式 Go to: https://hk.canon/en/support/imageCLASS%20LBP913w/model, download the printer driver
- 12. 選擇並下載以下檔案

Choose and download below files:

- 打印機驅動程式 / Printer Driver [Windows xxbit] LBP113w/LBP913w UFRII LT Printer Driver Ver.xx.xx
- 13. 下載的文件以自解壓縮檔檔案(.exe 格式)保存在指定的文件夾中,打開文件解壓縮。將在同一文件夾中創建新文件夾。新文件夾的名稱與解壓縮文件的名稱相同,進入新文件夾開啟「Setup.exe」開始安裝

Open the downloaded file, a same name new folder will be created. Go into new folder open "Setup.exe" start installation"



14. 選擇「Yes」



This is a legal agreement ("Agreement") between you and Canon Inc. ("Canon") and governing your use of Canon's software programs including the related manuals or any printed material thereof (the "SOFTWARE") for certain Canon's copying machines, printers and multifunctional peripherals (the "Products").


READ CAREFULLY AND UNDERSTAND ALL OF THE RIGHTS AND RESTRICTIONS DESCRIBED IN THIS AGREEMENT BEFORE V

Do you agree to the terms in license agreement?

Yes No


選擇「Standard」,按「Next」 15.

Choose "Standard", press "Next"




The UFR II printer driver will be installed on your computer. Select a setup method, and then click [Next].






16. 等待搜尋印表機


Wait for searching printer






18. 確定印表機資料,按「Start」

Confirm printer information, press "Start"




19. 等待安裝程序完成

Wait for the installation progress



20. 按「Exit」完成安裝

Click "Exit" to finish installation



-完--End-