<u>LBP664Cx 在 Windows 透過 USB 連線連接印表機之驅動程式步驟</u> Driver installation procedure for LBP664Cx in Windows (Via USB)

- **注意: 安裝驅動程式前請勿接駁 USB 線,以免系統發生錯誤**
- ** Please don't plug the USB cable until the driver asked to do so**

下載及安裝步驟

Driver download and Installation procedure

- 1. 到佳能網站 https://hk.canon/en/support/imageCLASS%20LBP664Cx/model, 下載印表機的驅動程式 Go to: https://hk.canon/en/support/imageCLASS%20LBP664Cx/model, download the printer driver
- 2. 選擇並下載以下檔案


Choose and download below file:

- 打印機驅動程式 / Printer Driver

[Windows xxbit] Generic Plus UFR II Printer Driver Vx.xx


3. 下載的文件以自解壓縮檔檔案(.exe 格式)保存在指定的文件夾中,打開文件解壓縮。將在同一文件夾中創建新文件夾。新文件夾的名稱與解壓縮文件的名稱相同,進入新文件夾開啟「Setup.exe」開始安裝

Open the downloaded file, a same name new folder will be created. Go into new folder open "Setup.exe" start installation"



4. 選擇語言(Language),然後按「Next」

Select Language, press "Next"



5. 選擇「Yes」

Choose "Yes"

License Agreement

Please read the following license agreement completely and carefully. Click [Yes] to agree to the license agreement.




CANON SOFTWARE LICENSE AGREEMENT IMPORTANT This is a legal agreement ("Agreement") between you and Canon Inc. ("Canon") and governing your use of Canon's software programs including the related manuals or any printed material thereof (the "SOFTWARE") for certain Canon's copying machines, printers and multifunctional peripherals (the "Products"). READ CAREFULLY AND UNDERSTAND ALL OF THE RIGHTS AND RESTRICTIONS DESCRIBED IN THIS AGREEMENT BEFORE > Do you agree to the terms in license agreement?

6. 選擇「USB Connection」,按「Next」 Choose "USB Connection", press "Next"

The Generic Plus UFR II printer driver will be installed on your computer. Select a setup method, and then click [Next].





7. 接「Yes」 Press "Yes"



Installation cannot be canceled once started. Do you want to continue?



8. 等待安裝程序完成

Wait for the installation progress

Installing...

The program features you selected are being installed.



	-
Setup Wizard is installing the UFR II printer driver. Please wait	
Status: Registering printer	

接駁 USB 線及開啟印表機 9.

Connect device with USB cable and switch on the printer

USB Connection



Follow the steps below to install the printer driver:

Status:


- Connect the USB cable to the computer.
 Connect the USB cable to the printer.
 If the printer power is off, turn on the printer. The printer will be recognized automatically and installation of printer drivers will start.

If the printer is not automatically recognized even with the USB cable connected, disconnect the cable from the printer after turning off the printer, and then connect the cable again.

Skip

10. 成功偵測印表機後按「Exit」完成安裝

Click "Exit" to finish installation after device detected by computer.



-完-

-End-