

在 Windows 以網路接駁安裝 MG3670 驅動程式步驟

MG3670 printer driver Installation Guide for Windows (Via Network)

以下步驟及畫面僅供參考，實際操作畫面可能因裝置型號、系統或軟件版本而有所不同。

The following steps and screens are for reference only, and the actual operation screens may vary depending on the device model, system, or software version.

點擊以下連結下載有關之驅動程式:

<http://ugp01.c-ij.com/ij/webmanual/WebPortal/PTL/ptl-setup.html?lang=tc&type=setup&area=hk&model=mg36&os=w>

Click below link for download printer driver:

<http://ugp01.c-ij.com/ij/webmanual/WebPortal/PTL/ptl-setup.html?lang=en&type=setup&area=hk&model=mg36&os=w>

下載及安裝步驟

1. 按一下「下載」。下載完成後開啟該檔案安裝

Click "Download", open the file after download completed


2. 打開安裝程式後按「開始設定」

Click "Start Setup" after open the installation program




3. 在居住地選擇「亞洲」，國家或地區選擇「中國香港特別行政區」，再按「下一步」

Select "Asia" for place of residence, choose "Hong Kong SAR China" for country or region, and then click "Next"




4. 按「是」同意許可協定

Click "Yes" to accept the license agreement



5. 可選擇是否同意傳送資訊至佳能，按「同意」或「不同意」

Select “Agree” or “Disagree” send information to Canon Extended Survey Program



6. 閱讀指示後按「下一步」

Read the instruction then click “Next”



7. 於連接方法選擇「無線 LAN 連接」，然後按「下一步」

Select “Wireless LAN Connection” when choosing connection method, then click “Next”



8. 按「下一步」

Click “Next”



9. 確定印表機已開啟及連接網路，在「網路上印表機的清單」勾選印表機，按「下一步」(如清單上沒有印表機，跳至步驟 11)

Make sure printer is on and connected to network, select printer at "Printers on Network List" then click "Next" (If no printer on the list, jump to [step 11](#))



10. 等待電腦下載及安裝驅動程式，跳至步驟 26

Waiting for complete download and install printer driver, jump to [step 26](#)



11. 如清單上沒有印表機，請勾選「在清單中無法找到設定的印表機」，按「下一步」

If there is no printer on the list, click "Setting printer could not be found on the list", click "Next"




12. 如印表機上 Wi-Fi 指示燈閃爍，按印表機上停止 (Stop) 按鈕，然後按「下一步」

If the Wi-Fi lamp on the printer is flashing, press the "Stop" button, then click "Next"




13. 根據畫面指示按鍵，首先按住印表機上的“無線”按鈕，直至電源指示燈閃爍，接著按一次彩色按鈕，再按一次“無線”按鈕，最後按「下一步」繼續 (如電腦不支援無線連線，直接按「下一步」跳過此步驟，跳至步驟 17)

Follow the instructions and press the button. Firstly, press and hold the “Wireless” button on the printer until the wireless lamp flashes, then press “Color” button, followed by the “Wi-Fi” button again. Finally click “Next” to continue (If the computer does not support Wi-Fi, click “Next” without press button, jump to [step 17](#))




14. 等待完成印表機網路設定

Waiting for complete printer wireless setup



15. 連接完成後，按「下一步」

Setup complete, click "Next"



16. 等待電腦下載及安裝驅動程式，跳至步驟 26

Waiting for complete download and install printer driver, jump to [step 26](#)



17. 如電腦不支援無線網路連線或出現連線失敗的下畫面，按「下一步」繼續

If the computer do not support Wi-Fi network or connection failed, click "Next" to continue




18. 如印表機上 Wi-Fi 指示燈閃爍，按印表機上停止按鈕，然後按「下一步」繼續

If the Wi-Fi lamp on the printer is flashing, press the "Stop" button, and click "Next" to continue



19. 在連接方法按「使用 USB 電纜線的無線設定」

Click "Wireless Setup Using the USB Cable" for connection method



20. 等待電腦下載及安裝驅動程式

Waiting for complete download and install printer driver



21. 出現無法在網路上偵測到印表機時，勾選「透過 USB 設定網路連接」，按「下一步」

When the printer cannot be detected on the network appear, tick "Set up the network connection via USB", click "Next"




22. 以 USB 電纜線連接印表機和電腦，等待自動偵測印表機


Connect the printer and the computer using the USB cable, wait until printer is detected



23. 選擇要連接到的無線路由器，輸入密碼 (網路金鑰) 後按「連接」
Select access point and input password (Network Key), then click "Connect"



24. 如要求輸入管理員密碼，請按以下步驟列印網路設定，然後輸入密碼，再按「確定」
If asked to input Administrator Password, please refer to below steps and print the network settings, then input the password and press "OK"



- a. 在打印機放入紙張後，按住打印機的 Wi-Fi 按鈕，直至電源指示燈閃爍後鬆開
After loading paper into the printer, then press and hold Wi-Fi button of the printer and release it when ON lamp flashes
- b. 再次按 Wi-Fi 按鈕
Press Wi-Fi button again
- c. 打印 Network Configuration Page 後，上面的 Default Password 為管理員密碼
After printing the Network Configuration Page, the "Default Password" is the administrator password

```
*****
*** Network Configuration Page ***
*****
```

Product Information	
Product Name	MG3600 series
ROM Version	3.000
Serial Number	
Default Password	

25. 完成設定後斷開 USB 連線，按「下一步」

Disconnect USB cable after setup, click "Next"




26. 無線網路設定及驅動程式安裝完成，按「完成」繼續其他安裝程序

Wi-Fi setting and driver install complete, click "Finish" and continue install other process



27. 安裝完成後可按「執行」列印測試頁，如發生列印錯誤可能需重新安裝

After installation can click "Execute" for print test page, if problem occur may need to re-install driver



28. 驅動程式安裝完成，安裝軟件請按「下一步」

Driver installation complete, click "Next" for install software




29. 在軟體安裝清單勾選所需軟件，按「下一步」
Choose the desired software from the list and click "Next"



30. 如出現系統發現舊版本，按「確定」後會重啟電腦，重新啟動後安裝程式會自動啟動
If the system found an old version, click "OK" to restart computer then driver install wizard will auto restart



因為系統中發現檔案的舊版本，檔案被更新。立即重新啟動系統以完成更新。按一下 [確定] 重新啟動系統。系統重啟後，該軟體將自動重新啟動。



31. 按「結束」完成安裝

Click "Finish" to complete installation



-完-

-End-