



LBP8780x 以 USB 連線連接印表機安裝驅動程式步驟 (以 Win 10 作示範)
The driver installation procedure for LBP8780x (Via USB)(Win 10 as example)

****注意: 安裝驅動程式前請勿接駁 USB 線，以免系統發生錯誤****
**** Please don't plug the USB cable until the setup program asked to do so**


1. 到佳能網站 <https://hk.canon/en/support/imageCLASS%20LBP8780x/model>，下載印表機的驅動程式 – UFR II Printer Driver
(Go to: <https://hk.canon/en/support/imageCLASS%20LBP8780x/model>, then download the printer driver – UFR II Printer Driver)
2. 下載的文件以自解壓縮檔檔案(.exe 格式)保存在指定的文件夾中，打開文件解壓縮。將在同一文件夾中創建新文件夾。新文件夾的名稱與解壓縮文件的名稱相同 (Open “UFR II_Driver_***.exe”; a new folder will be created.)
-如打開文件解壓縮時出現「使用者帳戶控制」選項，請按「是」 (If “User Account Control” window pops up, please click “Yes”)



3. 進入「Driver」文件夾，然後開啟“Setup.exe” (Go into “Driver” folder, then open “Setup.exe”)



4. 按「Yes」 (Click “Yes”)




5. 選「USB Connection」，按「Next >」(Select “USB Connection”, then Click “Next >”)

The UFR II printer driver will be installed on your computer.
Select a setup method, and then click [Next].



Printer Setup



- Standard
Search for printers on the network and install.
 Reactivate Printers in the Sleep Mode and Search
- Custom
Specify a port or an IP address manually to install drivers of local or network printers.
You can also specify other settings, such as setting a printer as a shared printer.
- USB Connection
Connect the printer with a USB cable and install.

< Back Next > Cancel

6. 選「Add New Printers」，按「Next >」
(Select “Add New Printers”, then click “Next >”)

Select Process
Select the items to install and the process to install the printer driver.



UFR II Printer Driver

Process to Install Printer Driver


- Add New Printers and Update Existing Printer Drivers
- Add New Printers

Canon Driver Information Assist Service

By installing this service, you will be able to retrieve device information and perform Department ID Management and User Authentication from your computer when using shared printers.

< Back Next > Cancel

7. 以 USB 電纜線接駁打印機及電腦，然後開啟打印機 (Connect printer and computer with the USB cable, and then turn on the printer)



1

2

3

Follow the steps below to install the printer driver:

Status:


1. Connect the USB cable to the computer.
2. Connect the USB cable to the printer.
3. If the printer power is off, turn on the printer.

The printer will be recognized automatically and installation of printer drivers will start.

If the printer is not automatically recognized even with the USB cable connected, disconnect the cable from the printer after turning off the printer, and then connect the cable again.

Skip

8. 建議別選「Restart My Computer Now」，按「Restart」重新開機 (We recommend choose "Restart My Computer Now", and then restart computer)



Installation is complete.

Restart My Computer Now

Restart

-完-
-End-