


清潔自動送稿器掃描玻璃 Clean the feeder platen glass

原因:

Cause:

使用自動送稿器作影印或掃描時出現直線條紋

Steaks appear when using feeder to copying or scanning



解決方案:

Solution:

使用柔軟、乾淨、無絨的乾布清潔自動送稿器掃描玻璃（以黃色箭咀示）

Use a soft, clean, lint-free and dry cloth to clean the platen glass for feeder (Shown as yellow arrows)


例子一 - 多功能噴墨印表機（以MB5370為例）

Example 1 - Multi-functional inkjet Printer (MB5370 as example)



例子二 - 多功能噴墨印表機 (PIXMA MX497)

Example 2 - Multi-function inkjet Printer (PIXMA MX497)



例子三 - 多功能雷射印表機 (以MF729Cx為例)

Example 3 - Laser All-in-One Printer (MF729Cx as example)



-完-
-End-