
## 如何使用Canon Connect Station應用程式上載/下載相片 How to use Canon Connect Station app to upload / download photos

請確保CS100和輸出螢幕經已連接並開啓電源 Please ensure CS100 and output device is connected and powered on

連接CS100到Wi-Fi網絡 Connect CS100 to the Wi-Fi Network

1. 使用遙控器選擇"喜好設定"<sup>,</sup>然後按SET按鈕
Use remote control to select "Preferences", and then press SET button




2. 於 選擇"Wi-Fi設定",然後按SET按鈕

Select "Wi-Fi settings" at , and then press SET button




3. 選擇"尋找網絡",然後按SET按鈕
Select "Find network", and then press SET button



4. 於"找到的週邊設備"選擇路由器名稱,然後按SET按鈕
Select router's name at "Peripherals found", and then press SET button



5. 輸入Wi-Fi密碼,然後選擇"確定"並按SET按鈕 Input Wi-Fi password, and then select "OK" and press SET button



6. 連接後,然後按SET按鈕

After connected, and then press SET button



## 請確保智能裝置已連接至相同的Wi-Fi網絡

Please ensure smart device is connected to the same Wi-Fi network

使用Connection Station應用程式上載/下載相片(以iOS 為例子) Use Connect Station app to upload / download photos (iOS as example)




1. 於App Store / Play Store 下載 Canon Connect Station 應用程式 Canon



Download Canon Connect Station app

at App Store / Play Store

2. 下載完成後,開啓Canon Connect Station應用程式 Open Canon Connect Station app when download is completed



Canon


3. 點選"選取"以進行下載相片

Tap "Select" to download photos



4. 點選需下載的相片,然後點選 📥

Tap the photos need to download, then tap  $\stackrel{\checkmark}{\sqsubseteq}$ 



## 5. 請等待下載完成

Please wait for downloading until it finished




6. 如需上載相片,可以於主畫面點選 + 開啓電話裝置內的相片集

Tap + at main menu to open album of mobile device if need to upload photos



## 7. 點選"選取"

Tap "Select"



8. 點選需上載的相片,然後點選 🗘

Tap the photos need to upload, then tap  $\triangle$ 



714 個項目

土

9. 請等待上載完成

Please wait for uploading until it finished



10.上載完成後,輸出裝置的主螢幕中"接收到新影像"會顯示 ↔

After uploaded, "New images received" will display 🔁 at output device main menu

