

MF515x 在 Windows 透過 USB 連線連接印表機之驅動程式步驟
Driver installation procedure for MF515x in Windows (Via USB)

****注意: 安裝驅動程式前請勿接駁 USB 線，以免系統發生錯誤****
**** Please don't plug the USB cable until the driver asked to do so****

下載及安裝步驟

Driver download and Installation procedure

1. 到佳能網站 <https://hk.canon/en/support/imageCLASS%20MF515x/model>，下載印表機的驅動程式

Go to: <https://hk.canon/en/support/imageCLASS%20MF515x/model>, download the printer driver

2. 選擇並下載以下檔案

Choose and download below files:

- 打印機驅動程式 / Printer Driver


[Windows x64bit] imageCLASS MF515x MFDivers (UFR II / PCL / PS3 / FAX / ScanGear)

- 掃描器軟件 / Scanning software

[Windows 32bit & 64bit] MF Scan Utility Ver.x.x.x.x


3. 下載的文件以自解壓縮檔檔案(.exe 格式)保存在指定的文件夾中，打開文件解壓縮。將在同一文件夾中創建新文件夾。新文件夾的名稱與解壓縮文件的名稱相同，進入新文件夾開啟「Setup.exe」開始安裝

Open the downloaded file, a same name new folder will be created. Go into new folder open "Setup.exe" start installation"




4. 選擇「Yes」


Choose "Yes"



5. 選擇「USB Connection」，按「Next」
Choose “USB Connection”, press “Next”




6. 等待安裝程序完成
Wait for the installation progress



7. 接駁 USB 線及開啟印表機

Connect device with USB cable and switch on the printer

USB Connection



Follow the steps below to install the printer driver:

Status:

1. Connect the USB cable to the computer.
2. Connect the USB cable to the printer.
3. If the printer power is off, turn on the printer.

The printer will be recognized automatically and installation of printer drivers will start.


If the printer is not automatically recognized even with the USB cable connected, disconnect the cable from the printer after turning off the printer, and then connect the cable again.

Skip

8. 成功偵測印表機後按「Exit」完成安裝

Click "Exit" to finish installation after device detected by computer.

UFR II Printer Driver - Ver. 30.12




Installation is complete.
Click [Exit] to quit the wizard.

Restart My Computer Now


The scanner driver for this device, or the driver for Canon USB devices, is not installed.
Refer to the instruction manual for the appropriate device, and install the necessary driver separately.

Exit


9. 執行檔案〔MFScanUtility_XXXXX_EN.exe〕按「Next」
Run the file [MFScanUtility_XXXXX_EN.exe], click "Next"




10. 按「Yes」
Click "Yes"



11. 等待安裝程序完成
Wait for the installation progress



12. 按「Complete」完成安裝
Click "Complete" to finish installation



-完-
-End-