

在 Windows 以 USB 方式安裝及連接 PIXMA TS3470 打印機（以 Windows 10 作示範）

Installing PIXMA TS3470 on Windows via USB connection (Use Windows 10 as example)

****注意: 安裝驅動程式前請勿接駁 USB 線，以免系統發生錯誤****

**** Please don't plug the USB cable until the driver asked to do so****

下載及安裝步驟

Driver download and Installation procedure

1. 到以下佳能網站並下載印表機的驅動程式

https://hk.canon/zh_HK/support/TS3470/model

Go to below Canon webpage and download the printer driver

<https://hk.canon/en/support/TS3470/model>

2. 選擇並下載以下檔案

Choose and download below files

E3400/TS3400 series MP Drivers Ver.1.xx (Windows)

3. 按上面網頁內的〔下載〕，下載完成後開啟該檔案安裝

Click [Download] in the webpage above, and then execute the file after download was completed


4. 按〔下一步〕

Click [Next]




5. 選擇〔亞洲〕，按〔下一步〕

Select [Asia]; click [Next]




6. 按〔是〕

Click [Yes]



7. 如下圖所示，連接 USB 線，然後在清單中選擇連接方法為 USB 的打印機，按〔 下一步 〕
- As the illustration below, connect the USB cable, then select the printer with USB connection method from the list, click [Next]



Canon IJ Driver Installer

找到印表機。
請從清單中選擇印表機，然後按一下 [下一步]。

偵測到的印表機：

產品名稱	序號(最後 5 位數)	連接方法	IPv4 位址	IPv6
series	*****	USB	-	-

< >


重新搜尋

找不到印表機


依 IP 位址搜尋

下一步

8. 正在安裝印表機驅動程式，請稍候
Installing the driver, please wait



9. 安裝完成，按〔結束〕
Driver installation was completed; click [Finish]



-完-
-End-