無線設定 - 簡易無線連接 (iOS)

WiFi Setup - Easy Wireless Connect (iOS)

1. 在智慧型手機或平板電腦安裝 Canon PRINT Inkjet/SELPHY

Install Canon PRINT Inkjet/SELPHY on smartphone or table

iOS: https://apps.apple.com/hk/app/canon-print-inkjet-selphy/id664425773

2. 按以下網址並選擇支援的打印機型號,然後開啟簡易無線連接模式 https://ij.manual.canon/ij/webmanual/WebPortal/PTL/ptl-model.html?lng=tc&type=app5&area=hk

Please click the link below, and then choose the supported printer model to enable the Cableless setup mode https://ij.manual.canon/ij/webmanual/WebPortal/PTL/ptl-model.html?lng=en&type=app5&area=hk

3. 印表機準備工作完成時,顯示以下螢幕


When the printer preparation is complete, the screen below appears

Follow the instructions of Follow the instructions on your computer or smartphone.

Follow the instructions on your computer or smartphone.



4. 從裝置上的 Wi-Fi 設定中選擇印表機的網路名稱(以「Canon_ij_」開頭的 SSID)
Select the printer's network name start with (Canon_ij_) from the Wi-Fi settings on your smart device




5. 執行 Canon PRINT Inkjet / SELPHY Run the Canon PRINT Inkjet / SELPHY



6. 閱讀後按"同意"或"不同意"繼續


Read the information, then tap "Agree" or "Do not agree" to continue



7. 按"允許"

Tap "Allow"






8. 按"搜尋"

Tap "Search"





9. 按"好"

Tap "OK"





10. 按"如果找不到印表機"

Tap "If Printer Cannot be Found"



Searching...

11. 按"確定"

Tap "OK"



To setup the network connection, connect your smartphone directly to your printer. Select [Join] on the following dialog.

12. 請等候

Please wait




Searching for printers.
This may take up to 3 minutes.

Cancel

13. 接"加入"

Tap "Join"





14. 請等候

Please wait

正在搜尋印表機。 這可能需要 3 分鐘。	Searching for printers. This may take up to 3 minutes.
取消	Cancel

15. 點選要連接印表機的無線路由器 SSID


Tap the SSID of wireless router which you want the printer to connect



16. 輸入無線路由器密碼,然後按"確定"

Enter the password for wireless router, then tap "OK"






17. 請等候

Please wait





18. 按"關閉"

Tap "Close" to close





19. 接"×"關閉

Tap "X" to close

× ×






現在選擇您喜愛的相片並嘗試列印吧!

Now choose your favorite photo and try it out!

選擇影像 Select images

20. 按"×"關閉

Tap "X" to close



試試看!

Try it out!

Visit the Canon website for information on getting the most from your printer. From there you can download applications and access services.


×

型績 Continue

21. 按"使用 App 時允許"

Tap "Allow While Using App"





22. 設定完成

All set





-完-

-End-