

MF289dw 在 Windows 透過 Wi-Fi 連接印表機之驅動程式步驟
Driver installation procedure for MF289dw in Windows via Wi-Fi

以下步驟及畫面僅供參考，實際操作畫面可能因裝置型號、系統或軟件版本而有所不同。
The following steps and screens are for reference only, and the actual operation screens may vary depending on the device model, system, or software version.

先將打印機連接到網路，詳細可參考以下步驟


Connect printer to network first, please refer to following procedure

1. 開啟印表機

Turn on the printer

2. 在控制面板上，按下〔首頁〕畫面中的〔無線區域網路設定〕

On the control panel, press [Wireless LAN Set.] in the [Home] screen




3. 選擇想要連線的無線區域網路的 SSID

Select the SSID of the wireless LAN to which you want to connect




4. 輸入網路密碼，然後按〔套用〕

Enter the network key, and press [Apply]



5. 按〔是〕並等待畫面顯示〔已連線。〕

Press [Yes] and wait for the [Connected.] is displayed on the operation panel



等待約 2 分鐘，直到本機的 IP 位址設定完成

Wait approximately 2 minutes until IP address settings of the machine complete


下載及安裝步驟

Driver download and Installation procedure


6. 到以下網站下載印表機的驅動程式及掃描軟件
Go to below URL then download the printer driver and scanner software
<https://hk.canon/en/support/imageCLASS%20MF289dw/model>
7. 選擇並下載以下檔案：
Choose and download the file below:

Master Setup (Windows)

8. 執行檔案〔mastersetupvxxx.exe〕按「確定」
Run File [mastersetupvxxx.exe], click “OK”



9. 按「確定」
Click “OK”



10. 按「開始設定」
Click “Start Setup”



11. 請稍候
Please wait




12. 按「是」
Click “Yes”



13. 按「同意」
Click “Agree”



14. 請稍候
Please wait



15. 請確保印表機已開啟，再按「下一步」
Please check that the printer is turned on, and then click "Next"




16. 請稍候
Please wait



17. 選擇印表機，再按「下一步」
Choose the printer, then click "Next"



18. 請稍候
Please wait



19. 按「繼續」
Click "Continue"




20. 請稍候
Please wait



21. 按「下一步」

Click “Next”



22. 按「稍後」結束安裝

Click “Later” to finish installation



-完-
-End-