

在 Mac OS 以無線方式安裝及連接 imagePROGRAF PRO-310 打印機

Installing imagePROGRAF PRO-310 on Mac OS via WiFi connection

以下步驟及畫面僅供參考，實際操作畫面可能因裝置型號、系統或軟件版本而有所不同。

The following steps and screens are for reference only, and the actual operation screens may vary depending on the device model, system, or software version.


無線設定 Wireless Setup

1. 確保在開始無線連接設定之前，印表機已開啟。

如果電源開啟，電源指示燈將亮起。


Make sure printer is turned on before starting wireless connection setup.

If the power is on, the **ON** lamp will be lit.




2. 按主頁按鈕。

Press the **HOME** button.




3. 使用上或下 (▼▲) 按鈕選擇 **LAN 設定**，然後按 **OK** 按鈕。

Use the up or down (▼▲) button to select **LAN settings** and press the **OK** button.




4. 選擇 **Wi-Fi** 並按 **OK** 按鈕。

Select **Wi-Fi** and press the **OK** button.




5. 選擇 **Wi-Fi 設定** 並按 **OK** 按鈕。

Select **Wi-Fi setup** and press the **OK** button.




6. 選擇 **手動連接** 並按 **OK** 按鈕。

Select **Manual connect** and press the **OK** button.



7. 選擇無線路由器並按 **OK** 按鈕。

Select your wireless router and press the **OK** button.



如果顯示其他螢幕或未找到無線路由器，請參見「[疑難排解](#)」。

If a different screen appears or no wireless router is found, see "[Troubleshooting](#)."

如果未找到您的路由器，請確定您的路由器設定符合以下打印機的規格：

If you do not find your router, please ensure your router setting meets the below printer requirement:

a. 頻率 Frequency: 2.4GHZ

8. 按 **OK** 按鈕。

Press the **OK** button.



9. 輸入密碼。文字輸入區分大小寫。


Enter the password. Text entry is case-sensitive.



10. 輸入後，在鍵盤上選擇 **OK**，然後按 **OK** 按鈕。
After entry, select **OK** on the keyboard, and then press the **OK** button.



11. 按 **OK** 按鈕。
Press the **OK** button.




12. 顯示下方的螢幕時，請按 **OK** 按鈕。
When the screen on the below appears, press the **OK** button.



13. 按主頁按鈕。

Press the **HOME** button.



網路連接設定完成。

連接完成後，無線訊號標誌顯示在螢幕的右上方。

The network connection setup is now complete.

Once the connection is complete, wireless signal icon appears at the upper right of the screen.

下載及安裝步驟

Driver download and Installation procedure


14. 點擊以下連結下載有關之驅動程式：

Click the link below to download printer driver:

<https://hk.canon/en/support/imagePROGRAF%20PRO-310/model>

15. 選擇並下載以下檔案

Choose and download the file below




Master Setup (Mac)

<https://hk.canon/en/support/0200641904>

16. 按網頁內的〔Download〕按鈕，下載完成後開啟該檔案安裝

Click [Download] button in the webpage, and then execute the file after download was completed



17. 打開軟件後按〔Master Setup〕
Click [Master Setup] after open the software



18. 請輸入電腦帳號密碼，再按〔安裝輔助程式〕
Please type in the password of computer account, then click [Install Helper]



19. 在設定新印表機的視窗按〔開始設定〕
Click [Start Setup] on the windows of setting up new printer



20. 正在下載，請等候
Downloading, please wait




21. 按〔是〕同意許可協定

Click [Yes] to accept the license agreement




22. 可選擇是否同意傳送資訊至佳能，按〔同意〕或〔不同意〕

Click [Agree] or [Do not agree] for sending information to Canon Extended Survey Program




23. 請等候
Please wait



24. 確認印表機電源已開啟，再按〔下一步〕
Confirm power on the printer, then click [Next]



25. 請等候印表機偵測
Please wait for printer detection



26. 從清單中選擇印表機，再按〔下一步〕
Choose the printer from the list, then click [Next]



27. 再按〔繼續〕
Click [Continue] again



28. 成功偵查印表機後請等候安裝
Please wait for install after detect the printer




29. 請等候下載及安裝

Please waiting for download and install




30. 安裝後按〔新增印表機〕


Click [Add Printer] after installation



31. 選擇〔Canon PRO-310 series〕，再按〔加入〕
Choose [Canon PRO-310 series], then click [Add]




32. 請等候
Please wait



33. 新增印表機後按〔下一步〕
Click [Next] after add printer




34. 按〔下一步〕繼續
Click [Next] to continue



35. 請等候
Please wait



36. 安裝完成，按〔下一步〕
Installation complete, click [Next]



37. 安裝完成

Driver installation was completed



-完-

-End-