

在 Windows 以無線方式安裝及連接 PIXMA TR160 打印機

Installing PIXMA TR160 on Windows via WiFi connection

以下步驟及畫面僅供參考，實際操作畫面可能因裝置型號、系統或軟件版本而有所不同。


The following steps and screens are for reference only, and the actual operation screens may vary depending on the device model, system, or software version.

無線設定 Wireless Setup

1. 確保在開始無線連接設定之前，印表機已開啟。
如果電源開啟，電源指示燈閃爍，然後持續亮起。


Make sure the printer is turned on before starting wireless connection setup.

If the power is on, the ON lamp flashes and then remains lit.




2. 在主頁螢幕選擇齒輪圖案 ，然後按 **OK** 按鈕。

Select the gear icon  on the HOME screen, then press the **OK** button.



3. 選擇 **LAN 設定** 並按 **OK** 按鈕。

Select **LAN settings** and press **OK** button.



4. 選擇 **Wi-Fi** 並按 **OK** 按鈕。

Select **Wi-Fi** and press **OK** button.



5. 選擇 **Wi-Fi 設定** 並按 **OK** 按鈕。

Select **Wi-Fi setup** and press **OK** button.




6. 選擇 **手動連接** 並按 **OK** 按鈕。

Select **Manual connect** and press **OK** button.




7. 選擇無線路由器並按 **OK** 按鈕。

Select your wireless router and press **OK** button.



8. 如果顯示輸入密碼，請按 **OK** 按鈕。

If Enter the password is displayed, please press **OK** button.



9. 輸入密碼。 [文字輸入](#)區分大小寫。

Enter the password. [Text entry](#) is case-sensitive.




10. 輸入後，在鍵盤上選擇 **OK**，然後按 **OK** 按鈕。

After entry, select **OK** on the keyboard screen, and then press the **OK** button.




11. 如顯示已連接到無線路由器時，請按 **OK** 按鈕。

When the screen on the below appears, press the **OK** button.



12. 按**返回**按鈕，直到顯示主頁螢幕。

Press the **Back** button until the following HOME screen appears.



網路連接設定完成。

The network connection setup is now complete.

連接完成後，無線訊號標誌會顯示在螢幕的左上方。

Once the connection is complete, the wireless signal icon appears at the upper left of the screen.

下載及安裝步驟

Driver download and Installation procedure


13. 到以下佳能網站並下載印表機的驅動程式

Go to below Canon webpage and download the printer driver

<https://hk.canon/en/support/PIXMA%20TR160/model>

14. 選擇並下載以下檔案

Choose and download below file




Master Setup (Windows)

<https://hk.canon/en/support/0101116303>


15. 按網頁內的〔Download〕按鈕，下載完成後開啟該檔案安裝

Click [Download] button in the webpage, and then execute the file after download was completed




16. 打開軟件後選擇語言，然後按〔OK〕

Choose the language after open the software, then click [OK]



17. 在居住地選擇〔亞洲〕，再按〔確定〕
Select [Asia] for place of residence, and then click [OK]



18. 在設定新印表機的視窗按〔開始設定〕
Click [Start Setup] on the windows of setting up new printer



19. 正在下載，請等候

Downloading, please wait



20. 按〔是〕同意許可協定

Click [Yes] to accept the license agreement




21. 可選擇是否同意傳送資訊至佳能，按〔同意〕或〔不同意〕

Click [Agree] or [Do not agree] for sending information to Canon Extended Survey Program



22. 請等候

Please wait



23. 確認印表機電源已開啟，再按〔下一步〕

Confirm power on the printer, then click [Next]



24. 請等候印表機偵測

Please wait for printer detection



25. 選擇印表機，再按〔下一步〕，如未能偵測印表機，請檢查網路連線

Choose the printer, then click [Next], if printer cannot be found, please check the network connection

Master Setup

×

選擇印表機

請從清單中選擇要設定的印表機。如果多台印表機具有相同的產品名稱，請檢查序號。

產品名稱	序號(最後 5 位數)	IPv4 位址	IPv6 位址	MAC 位址
 W1000 series	00000	192.168.1.100	2001:0db8:0000:0000:0000:0000:0000:0000	00:00:00:00:00:00

[檢查序號](#)

找不到印表機

下一步

26. 成功偵查印表機後請等候安裝

Please wait for install after detect the printer




27. 按〔 下一步 〕

Click [Next]




28. 請等候安裝

Please wait for install



29. 安裝完成，按〔下一步〕

Installation complete, click [Next]



30. 安裝完成

Driver installation was completed



-完-

-End-